



INSTRUCTIONS

3" & 6.25" RakJak™ Crib Stands

Part # RJCRI3 & RJCRI625

Made in the USA

General Guidelines

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measurements when using this product.
- Parts and/or instructions are subject to change without notice.



Safety

- **NEVER use the RakJak™ Crib Stand as a Jack Stand.**
- **This unit is not designed to be used as a Jack Stand under any circumstance.**
- Before using the RakJak™ crib stands ensure other persons are clear of the vehicle and the crib stands.
- Wear proper personal protective equipment such as safety goggles and gloves
- Inspect to ensure that the crib stands are free from damage before use.
- Do not exceed the rated weight capacity of 6,000 lbs maximum per unit
- Only use on dry, level, hard surfaces.
- Ensure all four corners of crib stand are contacting the work surface.
- Another person, standing clear of the vehicle, should provide visual assistance when elevating or lowering the car.
- Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake.
- RakJak™ crib stands are designed to be used individually **ONLY WITH** RakJak™ Air Bag Jacks manufactured by Zendex Tool Corp.
- Never stack with another crib stand.
- Refer to RakJak™ Air Bag Jack instructions for additional safety measures





INSTRUCTIONS

3" & 6.25" RakJak™ Crib

Part # RJCRI3 & RJCRI625

Made in the USA

Operations

1. Inspect the RakJak™ Crib Stands to make sure they are not damaged.
2. Park the vehicle on level ground. Place the vehicle transmission in Park, or the lowest gear for manual transmissions, and engage the parking brake.
3. Place RakJak™ Air Bag Jack securely on the crib stand as shown diagram on pg 1.
4. Test inflate RakJak™ Air Bag Jack away from the vehicle first to ensure it is working properly.
5. Slide Crib Stand, with RakJak™ placed securely on top, underneath jack point of the vehicle. Another person, standing clear of the vehicle, should provide visual assistance during this process.
Note: Refer to the RakJak™ owner's manual accompanying for proper usage.
6. Once load has been lifted SLOWLY to the desired height place jack stands underneath vehicle to support it.
7. Inspect the perimeter of the vehicle to ensure the vehicle is secure and stable prior to engaging in any further activity.
8. In preparation for removing the car off the cribs stand and RakJak™, verify the parking brake is engaged and all persons are clear of the vehicle.

Product Warranty and Liability

RakJak™ Crib Stands purchased from an authorized dealer or directly from Zendex Tool Corp are backed by a one-year warranty. Our warranty is strictly limited to the repair or replacement of manufacturer defects and does not cover damage to a car, personal injury, labor, or any other damage or injury. Zendex Tool Corp is not responsible for the damage caused by improper or unintended use. In no event shall Zendex Tool be responsible for consequential damage or costs. The warranty shall terminate one year from the date of purchase by the original owner and is not transferable. Because we are continuously conducting research and development, specifications are subject to change without notice.

Questions? Please contact Zendex Tool Corp at 800-446-5257 or email support@zendextool.com